

## STACKER INSTRUCTION MANUAL

The Mobile Stackers are lifting devices featuring easy, flexible, reliable and safe operation suitable for transportation of loads in such applications as warehouses, manufacturing facilities, storerooms and workshops.

In order to help you use this piece of equipment correctly, please read the instruction manual carefully before operating. Unauthorized operation is forbidden. Failure to adhere to these points can result in damage to the truck and/or injury to the operator.

### **ATTENTION:**

1. Overloading is not permitted. All operation should be conducted within the rated load capacity.
2. Never stand or sit on the stacker while in operation.
3. Never put your hands, feet or any other part of your body underneath the frame or fork assembly.
4. Make sure that loads are evenly distributed on the forks. Do not concentrate loads at one point or load one fork more than the other. If the load is shorter than the forks, the load should always be placed at the back of the forks against the backrest. Never lift loads with only one fork, or with the tips of the forks as this may damage or tip the stacker.
5. Never move the truck while raising or lowering the forks.
6. Do not allow your stacker to drop from one level to another. A drop of one inch more than doubles the load during impact which can result in bending or breaking components of the truck.
7. Always ensure that the load is stable and secure before moving to eliminate the possibility of load shifting.
8. When not in use, the forks should be lowered to avoid potential injury.
9. The stacker is designed to be used on a flat and hard surface. Applying the brake is recommended for applications involving a slope.

**TROUBLESHOOTING:**


CONDITION	CHECK POINT	ACTION
Motor does not run	Battery	Possible shorted cell or discharged battery
	Battery cables	All connections must be tight and free of corrosion
	Solenoid switch	Use jumper cable to bypass solenoid. If motor runs, solenoid is defective and needs replacing
	Loose wires	Check other wire connections
Ammeter jumps back and forth	All above points	Battery in backwards
	Circuit breaker on charger	Check all point
Motor runs - will not raise or hold position	Release valve rod in pump	Be sure rod is not binding. Remove from pump and allow oil to drain from port to flush possible dirt from pump.
	Check oil level in reservoir	If low, fill to capacity - 1" from filler hole
Motor keeps running	Starting Switch	Replace
		Tap solenoid switch lightly on side to release contact wire
Carriage lowers too slowly	Rollers in mast	Check for binding
Carriage will not raise	Pump valve assembly	Remove assembly and let oil drain from unit to flush the opening. Reassemble,
Carriage will not lower	Release plunger	Adjust valve screen.

## OPERATION (Battery model):

1. Push the control lever forward to raise the fork assembly. Pull the handle backward to lower the fork assembly.
2. Mobile stackers are manually propelled. Push or pull using the handles (or the optional 5<sup>th</sup> wheel assembly) to maneuver the unit. Ensure that the operators feet are clear of the frame when moving the unit.
3. The battery should not be allowed to run down completely so Mobile Stackers are equipped with a 10 amp onboard charger. To recharge the battery simply plug the charger into any standard 110 volt outlet. The required charge time depends on the amount of usage. Normally a fully charged battery should offer 6 to 8 hours of operation time. Units used frequently can be plugged in overnight (to a maximum of 24 hours) to ensure battery levels. Units used sparingly may only need to be plugged in weekly for recharging. The charger has an overload protection feature to prevent damaging the battery.

## MAINTENANCE:

1. **Lubrication:** It is recommended that a good grade of light grease should be applied to lubricate chain, rollers and wheels monthly. Wipe mast channels and apply light grease sparingly to inside surface.
2. **Hydraulic System:** Remove breather and check level of hydraulic oil with Stacker on level floor and in lowered position. Oil level should be 1" below top of the tank. If oil level is too high, it may cause oil to surge out of breather; if it is too low, it may prevent full lift of carriage and/or damage pump. For abnormal oil losses, check system for leaks as fittings may work loose. A slight creeping of the carriage without load can be accepted in any hydraulic cylinder.
3. **Electrical System:** Check connections as loose connections are the principal cause of electrical problems.
4. Use premium HVI hydraulic oil or equal (Recommended: AW32 Standard Hydraulic Oil). Other oils, fluids or solvents may damage the hydraulic system.



WE RESERVE THE RIGHT TO CHANGE SPECIFICATIONS AND / OR DESIGN WITHOUT NOTICE OR OBLIGATIONS

### PARTS LIST - Standard Battery Model Stacker

Index No.	Part No.	Part Name	Index No.	Part No.	Part Name	Index No.	Part No.	Part Name
1	1001	Screen Assembly, Safety	19	1019	Piston	37	1037	Platform Assembly
2	1002	Spring, Compression	20	1020	U Cup	38	1038	Plate Assembly
3	1003	Washer, Flat	21	1021	Locking Washer	39	1039	Fork Assembly
4	1004	Pad, Brake	22	1022	Nut	40	1040	Rod, Brake
5	1005	Bolt & Nut	23	1023	Locking Ring	41	1041	Battery
6	1006	Bolt, Hexagon	24	1024	Roller Assembly	42	1042	Hand Grip
7	1007	Door	25	1025	Cylinder	43	1043	Charger
8	1008	Caster	26	1026	Adapter Union 90	44	1044	Cable Battery
9	1009	Bolt	27	1027	Hose Assembly	45	1045	Cable Battery
10	1010	Cylinder PACKING KIT	28	1028	Hose Assembly H.P.	46	1046	Motor
11	1011	Spiral Pin	29	1029	Elbow 90	47	1047	Pump
12	1012	Axle	30	1030	Bolt U	48	1048	Breathor Filler Cap
13	1013	Wheel	31	1031	Roller	49	1049	Starter Switch
14	1014	Wiper	32	1032	Bearing Roller	50	1050	Handle
15	1015	O Ring	33	1033	Nut	51	1051	Oil Tank
16	1016	Head (Top)	34	1034	Stud	52	1052	Hand Grip
17	1017	Piston Rod	35	1035	Roller Chain	53	1053	Hand Grip
18	1018	O Ring	36	1036	Fork Assembly	54	1054	BRAKE LEVER