

Phone: **260.665.7586**

Address: 2999 North Wayne Street, Angola, Indiana 46703, USA Fax: 260.665.1339 Visit us online: www.vestil.com

in 💆 f 👪

SQUARE COLUMN WRAP INSTALLATION INSTRUCTIONS



Step #1: Layout all pieces before starting installation to ensure the panel sizes and specific pieces are correct. There should be 8 pieces in total (4 corners & 4 flats).



Step #2: To start, place the first corner panel in place and slide down the flat panel, interlocking the sections.



Step #3: Once set, add the next corner panel in place by sliding it down to interlock with the already installed flat panel.







Phone: **260.665.7586**

Address: 2999 North Wayne Street, Angola, Indiana 46703, USA Fax: 260.665.1339 Visit us online: www.vestil.com

in 💆 f 📸

SQUARE COLUMN WRAP INSTALLATION INSTRUCTIONS



Step #4: Continue these steps by adding the next flat panel, then corner panel, and so on until the entire column is wrapped.



Step #5: Once all panels are locked into place, the Square Column Wrap is complete.



