

- 1) Use the four 2" x 5/16" bolts and 5/16" nuts to assemble crossbars and uprights as shown. Do not attach gas spring yet.
- 2) Anchor base to floor in desired location. (hardware not included).
- 3) Insert fixed upright into base. Raise gate. Attach gas spring as shown using 1 1/4" x 5/16" bolts and 5/16" nuts.

Base