


DIE

⚠ WARNING	⚠ ADVERTENCIA	⚠ AVERTISSEMENT
KEEP CLEAR OF PINCH POINT	MANTENGASE ALEJADO DEL PUNTO DE CORTE	SE TENIR À DISTANCE DU POINT DE PINCEMENT

208, both sides

⚠ WARNING	⚠ ADVERTENCIA	⚠ AVERTISSEMENT
Do not operate or move with unstable loads Do not load beyond rated capacity Distribute load evenly Do not tilt or ride	No opere ni se mueva con cargas inestables No cargue más allá de la capacidad nominal Distribuya la carga de manera uniforme No le sienten ni conduzcas	Ne pas utiliser ou déplacer avec des charges instables Ne pas charger au-delà de la capacité nominale Répartir la charge uniformément Ne vous asseyez pas et ne montez pas

658



ISO 32 / 150 SUS

HYDRAULIC OIL OR NON-SYNTHETIC TRANSMISSION FLUID
ACEITE HIDRAULICO O LIQUIDOS DE TRANSMISION NO SINTETICOS
HUILE OU LIQUIDE HYDRAULIQUE NON-SYNTHEIQUE

206

⚠ CAUTION	⚠ ATENCIÓN	⚠ ATTENTION
PLATFORM MUST BE LOWERED BEFORE MOVING LIFT	LA PLATAFORMA DEBE DE ESTAR EN LA POSICIÓN BAJA ANTES DE MOVER EL ELEVADOR	LA PLATE-FORME DOIT ÊTRE ABAISSÉE AVANT D'ACTIVER LE MONTE-CHARGE

210

MODEL / MODÉLO / MODÈLE _____
WEIGHT / PESO / MASS _____
CAPACITY / CAPACIDAD / CAPACITÉ _____
SERIAL / SERIE / SÉRIE _____
UNITS: 2.2 lb. = 1kg 1" (or 1in.) = 2.54cm 1153

1153 with 770 overlay

⚠ WARNING	⚠ ADVERTENCIA	⚠ AVERTISSEMENT
Immobilize by applying all caster brakes and/or floor locks when in use, loading, and unloading.	Immobilice aplicando todos los frenos de las ruedas y / o bloques del piso cuando esté en uso, cargando y descargando.	Immobiliser en appliquant tous les freins des roulettes et / ou les verrous de plancher lors de l'utilisation, du chargement et du déchargement.

212

Label 1072 is to be applied to the
outside of individual packaging

⚠ WARNING: Reproductive Harm - www.P65Warnings.ca.gov.	⚠ ADVERTENCIA: Daño Reproductivo - www.P65Warnings.ca.gov.
⚠ WARNING: Cancer - www.P65Warnings.ca.gov.	⚠ ADVERTENCIA: Cáncer - www.P65Warnings.ca.gov.

MANUAL DIE TABLE

9/15/2022