

FE-P



LABEL 625 UNDERSIDE OF BOTH EXTENSIONS

NOTICE
INSTALLATION INSTRUCTIONS

- 1 REMOVE PIN TO INSTALL FORK EXTENSION
- 2 SLIDE EXTENSIONS OVER FORK AGAINST THE FORK'S HEEL
- 3 REINSTALL LOCKING PIN BEHIND FORK HEEL

AVISO
INSTRUCCIONES DE INSTALACIÓN

- 1 DESMONTA EL PASADOR PARA INSTALAR LAS EXTENSIONES DE LA HORQUILLA
- 2 DESLIZA LAS EXTENSIONES SOBRE LA HORQUILLA CONTRA LA PARTE TRASERA DE LA HORQUILLA
- 3 REINSTALA EL PASADOR DE CIERRE DETRAS DE LA PARTE TRASERA DE LA HORQUILLA

AVERTISSEMENT
INSTRUCTION D'INSTALLATION

- 1 DÉFAIRE LA GOUPILLE POUR INSTALLER LE RALLONGE DE BRAS DE FOURCHE
- 2 GLISSER LES RALLONGES SUR LES BRAS DE FOURCHE ET CONTRE LE TALON DE FOURCHE
- 3 REMETTRE EN PLACE LA GOUPILLE D'ARRÊT DERRIÈRE LE TALON DE FOURCHE

697- 4" WIDE UNIT
698- 5" WIDE UNIT
699- 6" WIDE UNIT
1047 - 7" WIDE UNIT
1048 - 8" WIDE UNIT
UNDERSIDE OF BOTH EXTENSIONS

⚠ WARNING

Material handling is inherently dangerous. Improper or inappropriate use of fork extensions might result in operator or bystander death or serious injury.

- **DO NOT** use this extension if more than 150% of the fork time length.
- **DO NOT** use if locking loop is damaged or absent.
- **Law requires** you to contact (fork) lift truck manufacturer and request:
 1. Written approval **BEFORE** using fork extensions [29 CFR 1910.178(a)(4)].
 2. Markings for (fork) lift truck that:
 - Identify fork extensions;
 - Give approximate weight of truck and extensions at maximum evaluation with laterally-centered load, [29 CFR 1910.178(a)(5)].
- **DO NOT** use **UNTIL** lift truck manufacturer provides corrected capacity tags.

697
rev. 0520

CAPACITY, LOAD CENTER, AND FORK DIMENSIONS FOR FORK EXTENSION	Model	Extension		Fork Dimensions			Extension		Fork Dimensions		
		Capacity each Extension (kg)	Load Center (mm)	Max. Fork Thick (mm)	Nominal Fork Width (mm)	Min. Fork Length (mm)	Capacity each Extension (lb)	Load Center in.	Max. Fork Thick (in)	Nominal Fork Width (in)	Min. Fork Length (in)
CAPACITY, LOAD CENTER, AND FORK DIMENSIONS FOR FORK EXTENSION	FE-4-42	907.2	533.4	50.8	101.6	711.2	2,000	21	2	4	28
	FE-4-48	907.2	508.0	50.8	101.6	812.8	2,000	20	2	4	32
	FE-4-54	907.2	584.2	50.8	101.6	914.4	2,000	23	2	4	36
	FE-4-60	907.2	762.0	50.8	101.6	1016.0	2,000	30	2	4	40
	FE-4-63	907.2	698.5	50.8	101.6	1066.8	2,000	28	2	4	42
	FE-4-66	907.2	736.6	50.8	101.6	1117.6	2,000	29	2	4	44
	FE-4-72	907.2	812.8	50.8	101.6	1219.2	2,000	32	2	4	48
	FE-4-84	907.2	965.2	50.8	101.6	1422.4	2,000	38	2	4	56
	FE-4-90	907.2	1041.4	50.8	101.6	1524.0	2,000	41	2	4	60
	FE-4-96	907.2	1117.6	50.8	101.6	1625.6	2,000	44	2	4	64
	FE-4-108-P	907.2	1270.9	50.8	101.6	1828.8	2,000	50	2	4	72
	FE-4-120-P	907.2	1422.4	50.8	101.6	2032.0	2,000	56	2	4	80

LABEL 1210, UNDERSIDE OF BOTH EXTENSIONS

⚠ WARNING

Using this front end attachment exposes occupants and bystanders to risk of serious personal injuries or death.

1210

- **DO NOT** use this front end attachment with rough terrain lift trucks or telehandlers (boom lifts).
- **ONLY** use this attachment with high lift fork trucks utilizing a vertical mast and carriage.
- **DO NOT** operate truck with attachment on unimproved surfaces. **ONLY** operate the truck with the attachment on concrete or asphalt surfaces capable of supporting the truck and a full capacity load.

Label 1072 is to be applied to the outside of individual packaging

⚠ WARNING:
Reproductive Harm -
www.P65Warnings.ca.gov

⚠ ADVERTENCIA:
Daño Reproductivo -
www.P65Warnings.ca.gov

⚠ WARNING: Cancer -
www.P65Warnings.ca.gov

⚠ ADVERTENCIA: Cáncer -
www.P65Warnings.ca.gov

1072

FORK EXTENSION W/ PIN

03/27/2025