

RT-VML

⚠️ WARNING	⚠️ ADVERTENCIA	⚠️ AVERTISSEMENT
KEEP CLEAR WHEN IN USE	MANTENGASE ALEJADO CUANDO SE ESTA OPERANDO	SE TENIR À DISTANCE LORS DU FONCTIONNEMENT

220 Rev 08/03

LABEL 220, BOTH SIDES

MODEL / MODELO / MODÈLE _____
WEIGHT / PESO / MASS _____
CAPACITY / CAPACIDAD / CAPACITÉ _____
SERIAL / SERIE / SÉRIE _____
UNITS: 2.2 lb. = 1kg 1" (or 1in.) = 2.54cm 1153

LABEL 1153 W/770 OVERLAY

⚠️ WARNING	⚠️ ADVERTENCIA	⚠️ AVERTISSEMENT
KEEP CLEAR OF PINCH POINT	MANTENGASE ALEJADO DEL PUNTO DE CORTE	SE TENIR À DISTANCE DU POINT DE PINCEMENT

208

LABEL 208, BOTH SIDES

POWER OFF 5 SECONDS IF UNIT FAILS TO OPERATE
APAGUE 5 SEGUNDOS SI LA UNIDAD NO FUNCIONA
COUPER L'ALIMENTATION PENDANT 5 SECONDES SI L'UNITÉ NE FONCTIONNE PAS

656
REV0415

656, BY E-STOP

655, ON TILLER

RAISE HANDLE TO RESET
After Emergency Stop
ELEVE LA MANIVELA PARA QUE DESCANSE
Después de la parada de emergencia
LEVER LE LEVIER POUR FAIRE UN PAUSE
Après un arrêt brutal

vestil.com 655



LABEL 220

⚠️ WARNING	⚠️ ADVERTENCIA	⚠️ AVERTISSEMENT
KEEP CLEAR WHEN IN USE	MANTENGASE ALEJADO CUANDO SE ESTA OPERANDO	SE TENIR À DISTANCE LORS DU FONCTIONNEMENT

220 Rev 08/03

LABEL 206, ON RESERVOIR UNDER COVER

OUTRIGGER
Pin in extended position (perpendicular to chassis) before engaging load.

1231

LABEL 1231 - both sides

LABEL 1230

⚠️ WARNING
Serious personal injury or death can occur if this lifter is operated improperly.
• DO NOT operate until you read and understand entire owner's manual.
• DO NOT exceed the rated load or lift loads not specified in the owner's manual.
• DO NOT operate this lifter if damaged, malfunctioning, or missing parts.
• DO NOT operate lifter if indicators (pressure gauge) show inadequate vacuum. Alarm sounds when vacuum inadequate. DO NOT operate lifter if alarm sounding.
• DO NOT operate if vacuum pads not spaced for equal loading, or if pads positioned incorrectly on load.
• DO NOT use to lift people.
• NEVER lift loads over people.
• DO NOT leave suspended loads unattended. Unload lifter before leaving it unattended.
• DO NOT lift loads higher than necessary.
• DO NOT attempt to lift loads unless both outriggers pinned in extended positions.
• DO NOT transverse slop terrain. Only operate lifter on even, level intact concrete or asphalt.
• DO NOT remove or obscure any label, tag, or sign applied to lifter.
• DO NOT operate lifter if rated load, lifter weight, or safety markings (labels, tags signs) are missing or not easy to read.
• DO NOT make alterations to this lifter.
• DO NOT start or stop suddenly. Drive slowly and carefully while transporting loads. Sudden stops or starts could compromise grip on load.

1230

Label 1072 is to be applied to the outside of individual packaging

⚠️ WARNING: Reproductive Harm - www.P65Warnings.ca.gov.	⚠️ ADVERTENCIA: Daño Reproductivo - www.P65Warnings.ca.gov.
⚠️ WARNING: Cancer - www.P65Warnings.ca.gov.	⚠️ ADVERTENCIA: Cáncer - www.P65Warnings.ca.gov.

1072

ISO 32 / 150 SUS
HYDRAULIC OIL OR NON-SYNTHETIC TRANSMISSION FLUID
ACEITE HIDRAULICO O LIQUIDOS DE TRANSMISION NO SINTETICOS
HUILE OU LIQUIDE HYDRAULIQUE NON-SYNTHETIQUE

206
Rev. 1111

ROUGH TERRAIN VACUUM MOVER / LIFTER

01/28/2025