

# Vestil Manufacturing Corp.

2999 North Wayne Street, P.O. Box 507, Angola, IN 46703 Telephone: (260) 665-7586 OR Toll Free (800) 348-0868 Fax: (260) 665-1339

Web: www.vestilmfg.com e-mail: info@vestil.com

HSR-4860



### **Receiving Instructions**

After delivery, remove the packaging from the product. Inspect the product closely to determine whether it sustained damage during transport. If damage is discovered, record a complete description of it on the bill of lading. If the product is undamaged, discard the packaging.

**NOTE:** The end-user is solely responsible for confirming that product design, use, and maintenance comply with laws, regulations, codes, and mandatory standards applied where the product is used.

# **Technical Service & Replacement Parts**

For answers to questions not addressed in these instructions and to order replacement parts, labels, and accessories, call our Technical Service and Parts Department at (260) 665-7586. The department also be contacted online can at http://www.vestilmfg.com/parts info.htm.


### **Electronic copies of Instruction Manuals**

Additional copies of this instruction manual be downloaded may from https://www.vestil.com/page-manuals.php.

Table of Contents	Page
Specifications	2
Exploded View and Bill of Materials	3
Signal Words	3
Safety Instructions	4
Assembling the Rack	4
Installing the Rack	4
Loading the Rack	5
Record of Satisfactory Condition	5
Inspections & Maintenance	5
Labeling Diagram	5
Limited Warranty	6

# SPECIFICATIONS (31-007-360)


Specifications for the model HSR-4860 racks are provided on Vestil's website. To access the appropriate specifications document, navigate to this webpage: <a href="https://www.vestil.com/product.php?FID=1717">https://www.vestil.com/product.php?FID=1717</a>. Click the "Product Specifications Table" tab. Scroll the page to the table row for model HSR-4860 and click the button in the PDF column that looks like a pencil inside a box. A PDF file will open. This file is the specifications document. Print a copy of the document and keep it with your copy of this manual. The following is a copy of the specifications document. The document is current as of the publication date of this manual. If you have any questions about the specifications document, please contact the <u>TECHNICAL SERVICE</u> department.



		D BILL OF MATERIALS (31-006-360)	
ITEM	PART NO	DESCRIPTION	
<u>ITEM</u> 1	<b>PART NO.</b> 31-514-355	DESCRIPTION WELDMENT, FRAME, RACK	QTY.
ITEM 1 2	<b>PART NO.</b> 31-514-355 31-014-510	DESCRIPTION WELDMENT, FRAME, RACK FRAME, ARM, FORMED	

# SIGNAL WORDS

This manual uses SIGNAL WORDS to indicate the likelihood of personal injuries, as well as the probable seriousness of those injuries, if the product is misused in the ways described. Other signal words call attention to uses of the product likely cause property damage. The following are signal words used in this manual and their definitions.



# SAFETY INSTRUCTIONS

Vestil strives to identify foreseeable hazards associated with the use of its products. However, no manual can address every conceivable risk. The most effective way to avoid injury is to exercise sound judgment when assembling, using, inspecting, and maintaining this crane.

# **A** WARNING

Risks of serious personal injuries or death.

• **Read this manual in its entirety before assembling, using, inspecting or servicing the product.** Read the manual to refresh your understanding of use, inspection, and maintenance procedures as necessary. A copy of this manual should always be available to all persons who assemble, use, inspect and/or maintain this device.

• DO NOT use the product if any unusual noise or movement is observed.

• ONLY use/install this rack on even, level surfaces. DO NOT use the rack UNLESS it is securely anchored to a concrete surface capable of supporting the combined weight of the rack (~120lb.; 54.5kg) and a full capacity load (2,000lb; 909kg).

• Inspect & maintain the rack as instructed in the <u>INSPECTIONS & MAINTENANCE</u> section on p. 5. Do not use the rack unless it is in <u>SATISFACTORY CONDITION</u>. See <u>RECORD OF SATISFACTORY CONDITION</u>, p. 5. ONLY use manufacturer-approved replacement parts.

• DO NOT remove or obscure any label. Before using the rack, confirm that all labels are in place and easily readable. See <u>LABELING DIAGRAM</u> on p. 7.

• DO NOT climb on the rack.


• DO NOT apply loads weighing more than the capacity of this rack. The overall capacity of the rack is 2,000 pounds (909 kg). The capacity of each level (pair of rack arms) is 500 pounds (227kg). Do not apply more than 500 pounds to any pair of rack arms. Load the rack from the lowest level up. Center loads on the arm pairs. Loads should not overhang the arms by more than 12" (30cm).

• DO NOT pull or drag a loaded rack. Completely unload the rack before moving it.

• DO NOT modify the rack in any way. Modifying the rack automatically voids the <u>LIMITED WARRANTY</u> (on p. 6) and might make the rack unsafe to use.

# ASSEMBLING THE RACK

Insert the formed arms (31-014-510) into the arm receivers of the rack frame (31-514-355). Arm notches must face upwardly when installing the arms. The notch of each arm receives the rear wall of the inclined support. Insert an arm into the same receiver of each inclined support.



# **INSTALLING THE RACK**

Install the rack indoors on a level, even improved surface capable of supporting the combined weight of the rack (~120lb.; 54.5kg) and a full capacity load. The capacity of each arm pair is 500 pounds (227kg). Do not apply more than 2,000 pounds (909kg) overall to the rack. There are 4 bolt holes in the base frame of the rack for anchor bolts. Bolt hole location is diagrammed in *ASSEMBLING THE RACK*. Attach the rack to the floor with 1/2" anchor bolts that are at least 4" long.

# LOADING THE RACK

Install a pair of rack arms in the lowest arm receivers. Install the remaining arms where appropriate for your application. Load material onto rack arm pairs from the bottom up, i.e. load the lowest pair first. Apply loads as close to the inclined supports as possible.

# **RECORD OF SATISFATORY CONDITION (THE "RECORD")**

Before putting the rack into service, record its appearance. Thoroughly photograph the unit so that all features are clearly visible. Take close range photographs of each label and/or tag applied to the unit, the rack arms and arm receivers, and all anchoring hardware. Collect the photographs in a file. The file is a record of the unit in satisfactory condition. Do not use the rack unless all parts are in satisfactory condition.

# **INSPECTIONS & MAINTENANCE**

Compare the results of each inspection to the <u>RECORD</u> to determine whether all parts of the rack are in satisfactory condition. DO NOT use the rack unless all parts are in satisfactory condition. Only use manufacturer-approved replacement parts to restore the product to satisfactory condition. <u>Never make temporary repairs of damaged or missing parts</u>. **DON'T GUESS! If you have any questions about the condition of your unit, contact the** <u>TECHNICAL SERVICE</u> **department**. The phone number is provided on the cover page of this manual. Purely cosmetic changes, such as chipped paint, are not changes from satisfactory condition. However, unprotected steel rusts so touchup paint should be applied to all areas where the finish is damaged as soon as the damage occurs. Left unaddressed, rusting could compromise the soundness of the metal and create a safety hazard.


#### Unload the rack and inspect the following at least 1 time per month:

- 1) Rack arms: Remove each arm and its notch and inspect for bends, cracks, warps, rust/corrosion, and other forms of damage.
- 2) Frame: Closely examine all frame elements, arm receivers, and welds for rust, breaks, cracks, and other damage.
- 3) Anchor Bolts: Look for significant rusting/corrosion, damaged paint, and other damage around anchor bolts. Make sure that each bolt is solidly attached to the floor.
- 4) Labels: Confirm that each label is in place, undamaged, and easily readable.

Maintain the rack by replacing components that are not in satisfactory condition.

### LABELING DIAGRAM

Label content and location are subject to change so your product might not be labeled exactly as shown. Compare the diagram below to the <u>RECORD OF SATISFACTORY CONDITION</u>. If differences between applied labeling and this diagram exist, contact <u>TECHNICAL SERVICE</u>. Replace all labels that are damaged, missing, or not easily readable (e.g. faded). To order replacement labels, or to inquire whether your unit is properly labeled, contact the <u>TECHNICAL SERVICE AND PARTS DEPARTMENT</u> online at <u>http://www.vestilmfg.com/parts\_info.htm</u> or by calling (260) 665-7586 and asking for the Parts



Copyright 2021 Vestil Manufacturing Co.

# LIMITED WARRANTY



Vestil Manufacturing Corporation ("Vestil") warrants this product to be free of defects in material and workmanship during the warranty period. Our warranty obligation is to provide a replacement for a defective, original part covered by the warranty after we receive a proper request from the Warrantee (you) for warranty service.

#### Who may request service?

Only a warrantee may request service. You are a warrantee if you purchased the product from Vestil or from an authorized distributor AND Vestil has been fully paid.

#### Definition of "original part"?

An original part is a part used to make the product as shipped to the Warrantee.

#### What is a "proper request"?

A request for warranty service is proper if Vestil receives: 1) a photocopy of the <u>Customer Invoice</u> that displays the shipping date; AND 2) a <u>written request</u> for warranty service including your name and phone number. Send requests by one of the following methods:

<u>US Mail</u>	<u>Fax</u>	<u>Email</u>
Vestil Manufacturing Corporation	(260) 665-1339	<u>info@vestil.com</u>
2999 North Wayne Street, PO Box 507	<u>Phone</u>	Enter "Warranty service request"
Angola, IN 46703	(260) 665-7586	in subject field.

In the written request, list the parts believed to be defective and include the address where replacements should be delivered. After Vestil receives your request for warranty service, an authorized representative will contact you to determine whether your claim is covered by the warranty. Before providing warranty service, Vestil will require you to send the entire product, or just the defective part (or parts), to its facility in Angola, IN.

#### What is covered under the warranty?

The warranty covers defects in the following original, dynamic parts: motors, hydraulic pumps, motor controllers, and cylinders. It also covers defects in original parts that wear under normal usage conditions ("wearing parts"), such as bearings, hoses, wheels, seals, brushes, and batteries.

#### How long is the warranty period?

The warranty period for original dynamic components is <u>1 year</u>. For wearing parts, the warranty period is <u>90 days</u>. Both warranty periods begin on the date Vestil ships the product to the Warrantee. If the product was purchased from an authorized distributor, the periods begin when the distributor ships the product. Vestil may, at its sole discretion, extend a warranty period for products shipped from authorized distributors by up to 30 days to account for shipping time.

#### If a defective part is covered by the warranty, what will Vestil do to correct the problem?

Vestil will provide an appropriate replacement for any covered part. An authorized representative of Vestil will contact you to discuss your claim.

#### What is not covered by the warranty?

The Warrantee (you) is responsible for paying labor costs and freight costs to return the product to Vestil for warranty service.

#### Events that automatically void this Limited Warranty.

- Misuse;
- Negligent assembly, installation, operation or repair;
- Installation/use in corrosive environments;
- Inadequate or improper maintenance;
- Damage sustained during shipping;
- Collisions or other accidents that damage the product;
- <u>Unauthorized modifications</u>: Do not modify the product IN ANY WAY without first receiving written authorization from Vestil.

#### Do any other warranties apply to the product?

Vestil Manufacturing Corp. makes no other express warranties. All implied warranties are disclaimed to the extent allowed by law. Any implied warranty not disclaimed is limited in scope to the terms of this Limited Warranty. Vestil makes no warranty or representation that this product complies with any state or local design, performance, or safety code or standard. Noncompliance with any such code or standard is not a defect in material or workmanship.

TABLE OF CONTENTS

Copyright 2021 Vestil Manufacturing Co.